

out there (you know we are talking about you). But a word of caution – enter in wrong values and your device will be extremely unstable. Understand the best values for your device and then and only then play around with this section. You can download the AutoKiller Memory Optimizer and it will give you the best values for your device for the Memory Adjustment section.

In the Battery Saving Tweak section, keep the Wi-Fi supplicant scan values between 80 to 999 (above 999 and it will revert to default and less than 80 will cause, you guessed it, instability). You can enable multi touch screen functionality if it is already not enabled by default on your device. Under the Dalvik VM! Tweaks if you find a code line

- `Dalvik.vm.dexopt- flags=m=y`
Change it to
- `Dalvik.vm.dexopt- flags=v=n,o=y`

You can tweak the time delay between call receiving and the ringing by changing the value of the `call_ring.delay` line. To change the USB debugging notification in your status bar, look for the line

- `Persist.adb.notify`

If you want to see the notification, keep the value at 1 or keep it 0 to disable this notification.

If you want the LED lights of your device to be on during the entire time the device is in active mode, change the value of `ro.mod.buttonlight.timeout`



Some ROMs are built with strong UI customisation options