

Coolant

Some coolers use water mixed with a coolant, while some use plain coolant. There are different types of coolant used in the AIOs today and knowing what is used in your AIO helps with the refilling process. If there's a transparent window in your AIO, then you will be able to see the colour of the coolant. If that changes drastically then you should get your AIO sent for RMA. If the warranty period is over, then find the inlet for your AIO and open it up. Empty the coolant and flush the insides with clean (distilled water, if possible). Then generate the coolant and pour it into the cooler slowly. Once you've topped it up to the brim, close tap the radiator and let



AIO coolant

all the air bubbles surface, then top it up again and close the inlet. Run the pump for a brief while outside your PC and take care of the remaining air bubbles in the loop. Once you've completely filled the loop, close the inlet and ensure you have it sealed by using a sealing compound.

Refilling an AIO is not advised since they weren't made to be refilled or serviced by users.

Pump

One of the places that can get gunked up in an AIO is the microchannels on the base plate. This is true if the coolant is mildly corrosive and over time, there is a lot of debris released into the coolant. This debris tends to accumulate in the microchannels. The base plate of your CPU block is easily