



Jump start the pump without powering on the other components in your system

system. Rather than starting the entire PC, there's another way to only start the pump using your own PSU or a secondary one. You will have to jump start the pump using a simple trick. Remove the cables from all the components in your system except the pump's power. Or if you're using a secondary PSU, then connect the pump power to the PSU. You will find a bridging plug or a jump starter for the 24-pin motherboard power connector where a wire has been inserted at two ports. The pump can be jump started with this bridge. If you don't have a similar bridge then you can use a wire or paperclip to jump start it on your own.

Leak test

While you're filling up the loop, you should start preparing for a leak test. This is to ensure that there aren't any leaks before you power your system. You have to be cautious while you're pouring the fluid with the pump turned on. The best way would be to turn it on at intervals rather than keeping it powered while you're pouring. When the reservoir fills up, jump start the pump until the reservoir is almost empty. Be very careful not to empty