

wired networks. With the help of advanced devices, anyone can access the internet via your broadband connection easily.

This kind of process is mainly known as piggybacking and it is not suitable for specific below-mentioned reasons:

- Your internet speed will decrease since you are sharing your internet connection with multiple devices.
- Your internet bill will get increased since more data will be used when multiple users are connected with the same internet connection.
- There is also a lot of chance of security issues. Someone may hack your device and access all your files without your knowledge via your Wi-Fi.

Accessing the router's settings:

In case your router does not have any apps to configure the settings option, then you can access the settings with the help of the web browser. You can make use of the IP address of the router.

- Open the command prompt on the windows system, and then you have to type ipconfig. Here, the IP address, which is listed as the default gateway is the ID address of your router.

The screenshot displays the web interface of a D-Link DIR-855 router. The left sidebar contains a menu with options: VIRTUAL SERVER, PORT FORWARDING, APPLICATION RULES, QOS ENGINE (highlighted), NETWORK FILTER, ACCESS CONTROL, WEBSITE FILTER, INBOUND FILTER, FIREWALL SETTINGS, ROUTING, ADVANCED WIRELESS, WDS, WI-FI PROTECTED SETUP, ADVANCED NETWORK, and GUEST ZONE. The main content area is divided into tabs: SETUP, ADVANCED (selected), TOOLS, and STATUS. Under the ADVANCED tab, the 'QOS ENGINE' section is active, featuring a description of the QoS Engine and two buttons: 'Save Settings' and 'Don't Save Settings'. Below this is the 'WAN TRAFFIC SHAPING' section, which includes checkboxes for 'Enable Traffic Shaping' and 'Automatic Uplink Speed', both of which are checked. It also shows 'Measured Uplink Speed' as 'Not Estimated' and 'Manual Uplink Speed' set to '128 kbps'. The 'Connection Type' is set to 'Auto-detect'. Further down, it indicates 'Detected xDSL or Other Frame Relay Network' as 'No'. The 'QOS ENGINE SETUP' section at the bottom shows 'Enable QoS Engine', 'Automatic Classification', and 'Dynamic Fragmentation' all checked. The footer of the interface reads '10 -- QOS ENGINE RULES'.

Source: <https://images.dogeq.net/images/article/2019/10/keeper-2fa-3-100814406-large3x2.jpg>