

recovery mode, you need to manually check if your BIOS has any new updates. There is no autonomous way to do it.

Step 1: First, you need to find out your BIOS version, for that on search bar type msinfo, once it opens up a tab, you can see your BIOS version right below your processor's information.

Copy the version number and date of your BIOS and then visit your motherboard's support page. On that page, you can see if the latest version of the BIOS matches your version. If not, download the ZIP file and load it in your USB drive.

Alternative method: You can restart your PC and press the hotkey to open your BIOS setting. There you will see the BIOS control panel, and you can look for a feature that can search on the internet for the updated version of BIOS. But it's a rare chance you will find this feature in your BIOS setting.

Only high-end motherboards come with this feature, and sometimes even they are missing it. Having this feature, you get to relax as everything will be done on autopilot, and you just need to keep an eye on your system while BIOS is updating.

Step 2: Now, you have your BIOS update on USB flash drive. Restart your PC and go to your BIOS settings. Once you are in the control panel, launch the BIOS's firmware update tool to copy the current BIOS in your USB drive. If anything goes wrong, you can still reinstall your previous version and run your computer safely.

