

forward process. After removing the side brackets from the motherboard slot, gently insert the RAM module into the RAM socket.

You must exercise extreme caution during this stage since the RAM can only lock into the socket in one direction. Sometimes a firmer push is required to get the RAM into the right slot, but be cautious not to damage it. When the RAM is properly installed, the side brackets are intended to automatically lock in place.

Step 4: Attaching the motherboard to the frame

You must carefully install the motherboard onto the mining frame or whatever you are using as a replacement. You should use particular caution while handling the motherboard to avoid scratching the bottom. If you have mining equipment with a metal frame, the motherboard should only come into contact with the frame where screw holes are present. Tighten the screws to securely secure the motherboard.

Step 5: Connecting the Power Supply Unit

The Power Supply Unit should be located close to the motherboard. Make sure there is adequate room in the mining setup for the power supply. Look for the 24-pin power connection found on motherboards. They are typically equipped with a single 24-pin connection.

They must be securely linked to the motherboard otherwise the mining setup will not boot. The 8-pin power connection on the CPU should be linked to the motherboard nearest to the processor. Because the PCI-e 6+2 power conductor and the CPU connection are both 8 pin connectors, you should always be cautious not to mix them up. The CPU cable is thicker than the PCI-e cable.

Step 6: Connecting the USB risers

The x16 USB riser must be used in conjunction with the PCI-e x1, which is the shorter PCI-e x1 connection. This must be linked to the motherboard. An electric connection is required to power the risers. Depending on the type of your riser, you may require a PCI-e six-pin connection, a SATA cable, or a Molex connector to connect it.

Connect all of the correct power wires to each of the USB risers with caution. For each PSU cable, use up to two Molex or SATA connections. Connecting three or four power connections to three or four risers might harm them.