

on, it should automatically detect each of them and install the drivers for all of them. It takes a while for all of the GPUs to be correctly detected. Check if all of the GPUs are shown in Device Manager.

After all, GPUs are detected, set each one to mining (Compute) mode. By default, each GPU is in graphics mode; to enable optimal mining, set the “Global Graphics” “GPU Workload” for each GPU to COMPUTE from Graphics. Even if you’ve changed it to Compute, it’s likely that the GPU still says “Graphics” after all the changes. To resolve this, try restarting your computer and check if the value was saved correctly.

Setting the GPU BIOS MOD

Each GPU has its own bios, which instructs it on how to operate. Your GPU has four different memory types: Samsung, Micron, Elpida and Hynix. You will only use GPU memory for mining ethereum, which implies that the higher the memory quality, the higher the hashrate you can achieve. Hynix and Samsung memory types are slightly better than Micron and Elpida, but the variation is minimal.

To view what memory type your card has, download the GPU-Z tool. If you purchased all of your GPUs at the same time and they are the same card kind, and they all have the same Memory Type, that means they can all run on the same BIOS. By clicking on the button next to “BIOS Version,”



Lots of fans, lots of power