

you can export GPU BIOS. Make a backup of your original BIOS now that you've exported them before moving ahead.

Note: Always use the original BIOS for your cards; don't download random BIOS from the web because you can't be sure they're manufactured for your card type; even if they're the same model, they might not have the same BIOS. Working with the original card BIOS is critical in order to keep the risk to a minimum.

Steps to Flash the new GPU BIOS

Download the tool - ATIFlash.

Overlay your modified BIOS on top of your current one using ATIFlash. Make a backup of your current bios and store it safely.

If you're planning to flash a BIOS on a GPU, be rather mindful. When you are planning to flash on a BIOS, never have different card types plugged in at the same time to avoid accidentally flashing the wrong BIOS to the wrong card. If you use the ATIFlash correctly, it will notify and alert you that you won't be able to flash the specified BIOS since it's a different type of card than your original.

Save the bios you'll be flashing in the ATIFlash folder. Then, in the ATI-Flash folder, copy the file path location. Now, hold down the Windows key and the S key. Then press CMD. 'Command Prompt' will be the first result. Select 'Run as Administrator' from the context menu after right-clicking it.

Type 'cd' in the console window to copy the path to the ATIFlash folder. Type 'ATIFlash -f -p o (saved bios name)' in the console window.

BIOS Flash Errors & Issues

- If the ROM file could not be read and error occurs, change the Riser your GPU is linked to or connect that GPU directly to the motherboard. Alternatively, use DDU to reinstall the existing driver and install the driver again. If this does not resolve the issue, try downloading ATIFlash 2.74 Version and using it instead.
- If you get an error message that says ID's mismatched, it means you're trying to flash the incorrect BIOS on your GPU.
- If you get a 4000 or 8000 bytes erroneous size error, it means you're flashing the wrong BIOS. You must always be alert while working on which BIOS you flash.
- If you don't detect the GPU after flashing your GPU and restarting your computer, you didn't install the "Pixel Patcher" tool.