

Selection of voltage values for AMD visual cards' cores AMD GPU core downvoltage values must be chosen from the preset table in the Overdrive-NTool window's left column.

The values must be set pre-



HWiNFO64 v5.56-3230 Sensor Status [120 values hidden]

Sensor	Current	Minimum
Read Activity	0.0 %	0.0 %
Write Activity	0.2 %	0.0 %
Total Activity	0.2 %	0.0 %
Read Rate	0.000 MB/s	0.000 MB/s
Write Rate	0.270 MB/s	0.000 MB/s
Read Total	2,085 MB	2,085 MB
Write Total	766 MB	765 MB
GPU [#1]: AMD Radeon RX 580:		
GPU Memory Errors	11	11
GPU [#2]: AMD Radeon RX 580:		
GPU Memory Errors	69	69
GPU [#3]: AMD Radeon RX 580:		
GPU Memory Errors	1	1
GPU [#4]: AMD Radeon RX 580:		
GPU Memory Errors	5	5
GPU [#5]: AMD Radeon RX 580:		
GPU Memory Errors	0	0
GPU [#6]: AMD Radeon RX 580:		
GPU Memory Errors	14	14
Network: RealTek Semiconductor...		
Total DL	0 MB	0 MB
Total UP	0 MB	0 MB
Windows Hardware Errors (WHEA)		
Total Errors	0	0

0:00:08