

sional technician to diagnose and fix the issue to avoid causing further damage to your computer.

Blank screen on bootup

When you turn on your computer, if the screen remains blank or black, it can be frustrating and indicate that there's an issue with your system. Here are some possible causes of a blank screen on bootup:

1. **Monitor or display issues:** The issue could be with the monitor or the display cable. Make sure that the monitor is properly connected to the computer and that the display cable is working correctly.
2. **Graphics card issues:** If there is a problem with the graphics card, it may cause a blank screen on bootup. Try reseating the graphics card or replacing it.
3. **Power supply issues:** If there is a problem with the power supply, it may cause the computer to not boot up properly. Check that all power cables are properly connected and functioning correctly.
4. **BIOS settings:** Incorrect BIOS settings may cause the computer to not boot up properly. Make sure that the BIOS settings are correct.
5. **Hard drive issues:** If there is a problem with the hard drive, it may cause a blank screen on bootup. Try booting up the computer with a different hard drive or bootable USB.

If your computer is experiencing a blank screen on bootup, you can try the following steps to troubleshoot the issue:

1. **Check the monitor and display cable:** Make sure that the monitor is properly connected to the computer and that the display cable is working correctly.
2. **Check the graphics card:** Try reseating the graphics card or replacing it.
3. **Check the power supply:** Check that all power cables are properly connected and functioning correctly.
4. **Check the BIOS settings:** Make sure that the BIOS settings are correct.
5. **Check the hard drive:** Try booting up the computer with a different hard drive or bootable USB.

Remember, a blank screen on bootup can be caused by a variety of issues. If you're unsure about what's causing the problem, it's best to seek the help of a professional technician to diagnose and fix the issue to avoid causing further damage to your computer.

Fixing BIOS time and settings resets

The BIOS (Basic Input/Output System) is a software program that runs on your computer's motherboard. It's responsible for initializing and testing the hardware components of your computer when you turn it on. Sometimes, you may notice that the BIOS time and settings have been reset to their default values. Here are some possible causes of BIOS time and settings resets:

1. **Dead or dying CMOS battery:** The CMOS battery is a small battery on the motherboard that provides power to the BIOS chip. If the battery is dead or dying, it may cause the BIOS time and settings to reset.
2. **Power surges or outages:** If your computer experiences a power surge or outage, it may cause the BIOS time and settings to reset.
3. **Overclocking:** If you have overclocked your system, it may cause the BIOS time and settings to reset.
If you notice that the BIOS time and settings have been reset, you can try the following steps to troubleshoot the issue:
 1. **Replace the CMOS battery:** If the CMOS battery is dead or dying, replace it with a new one.
 2. **Use a surge protector:** Use a surge protector to protect your computer from power surges.
 3. **Disable overclocking:** If you have overclocked your system, try disabling it to see if it resolves the issue.

Remember, BIOS time and settings resets can be caused by a variety of issues. If you're unsure about what's causing the problem, it's best to seek the help of a professional technician to diagnose and fix the issue to avoid causing further damage to your computer.



Incorrect boot attempts

When you turn on your computer, it needs to boot up from a specific device, usually the hard drive or SSD, that contains the operating system. Sometimes, your computer may attempt to boot up from an incorrect device, such as a USB drive or CD/DVD. Here are some possible causes of attempts to boot to an incorrect device:

1. **Incorrect boot order:** The boot order is the sequence of devices that the computer will try to boot up from. If the boot order is set incorrectly, the computer may attempt to boot up from an incorrect device.
2. **Bootable media inserted:** If there is bootable media, such as a USB drive or CD/DVD, inserted in the computer, it may attempt to boot up from that device instead of the hard drive or SSD.