



3. **Scroll wheel:** The scroll wheel is a small wheel between the two buttons that allows the user to scroll up and down on a page or document.
4. **Sensor:** The sensor is what detects the mouse's movement and sends signals to the computer to move the cursor on the screen. There are three types of sensors: mechanical, optical, and laser.
5. **Microcontroller:** The microcontroller is a small computer chip that controls the mouse's functions and communicates with the computer.
6. **Cable:** A wired mouse has a cable that connects it to the computer's USB port.
7. **Battery:** A wireless mouse requires a battery to function, either a disposable or rechargeable battery.
8. **Transmitter:** A wireless mouse also has a transmitter that sends signals to the computer via Bluetooth or a USB receiver.
9. **Circuit board:** The circuit board is the component that connects all the internal components of the mouse together.

Overall, each component of a mouse is crucial to its functionality, and any damage or malfunction can affect its performance. Regular maintenance, such as cleaning the sensor or replacing the battery, can help extend the life of your mouse.

How to maintain your mouse?

A computer mouse is an essential peripheral device that allows users to navigate and interact with their computers. Like any



electronic device, a mouse requires regular maintenance to ensure optimal performance and longevity.

In this section, we'll discuss how to maintain your computer mouse, from cleaning and troubleshooting to replacing components. Let's get started.

Clean your mouse regularly

The first step in maintaining your mouse is to clean it regularly. Over time, dust, dirt, and debris can accumulate on the surface of your mouse, affecting its functionality.

To clean your mouse, first, turn it off and unplug it from your computer. Use a soft, lint-free cloth to wipe down the surface of the mouse, paying attention to the buttons and the scroll wheel.

For more stubborn stains or dirt buildup, you can use a small brush or a cotton swab dipped in rubbing alcohol to clean the surface of the mouse. Make sure to let the mouse dry completely before using it again.

1. Check the mouse cable

If you're using a wired mouse, make sure to check the cable regularly for any signs of damage or wear. A frayed or damaged cable can cause the mouse to malfunction or stop working altogether.

If you notice any damage to the cable, it's best to replace it as soon as possible to prevent further damage to the mouse.

2. Troubleshoot connection issues

If your mouse is not working or is experiencing connection issues, there are a few things you can do to troubleshoot the problem.

First, check that the mouse is properly connected to your computer. For a wired mouse, make sure the cable is securely plugged into the USB port. For a wireless mouse, make sure the batteries are properly inserted, and the receiver is connected to your computer.

If your mouse still isn't working, try restarting your computer or updating your mouse drivers.

3. Replace worn-out components

Over time, the buttons on your mouse may become worn out or

