



Dinosaurs extinction

Meteores might not be the reason for Dinosaurs extinction. Check it out.
<http://dgit.in/DinoExtinction>



Threaded Messaging

According to Slack's CEO Threaded Messaging is really important and is on its way to the market.
<http://dgit.in/ThrdMess>

HOW TO CLEAN YOUR LAPTOP

Mehul Bhagwani

feedback@digit.in

Are you fed up with the slow performance of your laptop? Is your laptop over heating so much that you're unable to work? Do you want your laptop to work the way it used to when it was brand new? It's time for you to do some laptop maintenance. Your laptop, after many months of use might be filled with dust and that dust clogs the ventilation resulting in your device overheating and showing a reduction in performance.

REQUIREMENTS:

- **Brush** - A soft strength and medium strength brush is apt for dusting components within your laptop.
- **Screwdriver set** - Your laptop might use Torx, Philips or the regular (-) screws. Get the right set of screwdrivers.
- **Blower** - Using a blower over a brush will help you save time and be reduces the chances of damage to SMT components.
- **Thermal Paste** - A new tube of thermal paste will be needed while reseating the processor, we had a Thermalright CF III lying around so it was used in the process.
- **Tissue Paper** - You need to use the tissue paper to wipe off the old thermal paste on your heatsink.
- **Acetone** - Using Acetone can help you wipe the thermal paste.

When your laptop is overheating and not performing to it's full potential it needs maintenance but what if you can do that at home without going to the service center?



STEPS 1:

Here are all the basic requirements for the job. Which are already mentioned above, we have used an HP Laptop and the process may vary depending on the model of your laptop. Make sure you wear a static band while handling the internals to avoid static discharge.



STEPS 2:

Start by referring to your laptop's manual or watch disassembly videos for your laptop to get familiar with the process. Unscrew whichever screws are mentioned by the manual and then slide the plastic covering which will allow you to open your laptop.



STEPS 3:

Remove the cable which is connecting your hard drive to your laptop as shown in the picture. Be careful and gentle with the wiring as it is very delicate in strength and try to pull the wire using the black plastic strip which is attached to the connector. It should pop out easily.



STEPS 4:

When removing the hard drive make sure you are careful. Hard drives are prone to damage from physical shock and the same can be said for every other component. But when your precious data is at stake you know it's best to be as careful as you can be.



STEPS 5:

When you want to remove your RAM the easiest way is by unlocking the clips from both sides of the module and then when the RAM pops out from its position just remove it. Your laptop might have one or two modules situated one above the other. Remove both.



STEPS 6:

Unscrew your Wireless/Bluetooth Chip and gently remove it, make sure you remove the cables marked 1 and 2 carefully and remember which cable fits on which side. Remember to reconnect them during reassembly as these are the antennae for your Wi-Fi / Bluetooth.