

Burn failure, MMC password unknown, laptop BIOS password reset & more...

Wish you'd never had a computer? Let us solve your problems

Q DVD burning failure

I recently updated my Windows 7 PC. The computer is showing Error 0xc0000301: DVD burning failure. Please help me with this.

Naresh Ambulgekar

A Go to the following website and run the tool <http://dgit.in/OCfYhl>. If you still face problems after that, then update the firmware of your optical drive, you can find that on the support page of your optical drive's manufacturer. Then if your issue isn't resolved, open regedit.exe with Admin rights and delete the following key.

```
HKEY_LOCAL_MACHINE\SYSTEM\
CurrentControlSet\Control\
Class\{4D36E965-E325-11CE-BF01-
000000000000}
```



Upgrade your optical drive's firmware

Delete the drive from the Device Manager and restart your computer, it'll automatically detect and reinstall the drive. Hopefully, your problem should be resolved by this step.

Q Drive disappearance

I am having a problem with my laptop. The DVD drive is not showing up in my computer there are 2 partitions of my drive named C: and D: but the DVD drive (E:) is not showing up. Whenever I insert any CD/DVD it does not read. I checked up in device manager and found that CD/DVD ROM driver is missing. I checked here <http://support.microsoft.com/kb/314060> but

could not go with the steps please help me. System config given below:

- Acer Travelmate 2420
- Intel celeron M @ 1.50 GHz
- 40 GB HDD
- 64 MB Graphic Card
- Windows XP SP2
- 512 MB DDR2 RAM

It cannot read any CD, so I am thinking of repairing XP using a USB device. If repairing will make the drive work then please tell me how to setup boot menu for XP SP2 on a USB device. Thanks.

Tanmay Agarwal

A Your laptop seems pretty old, you'll have to figure out if it is still in working condition. If you have any Linux Live boot disc images then you can create a bootable USB stick using the tool from www.pendrivelinux.com. Boot into Linux and see if you can still access your optical drive. If it is working then you can follow the steps mentioned on the Microsoft page you've mentioned. It required you to modify a few registry entries or you could run the tool given here <http://dgit.in/OCfYhl>. To learn more about modifying the registry, go to <http://dgit.in/S5jn7i>. Do keep in mind that modifying the registry is slightly risky, so do have a repair DVD ready and create a backup before you proceed.

Q MMC password forgotten

I am a subscriber of Digit and a great fan of the magazine. Help me with these problems:

1. Help me remove the password from my MMC which I forgot.
2. How to get rid of write protection on the MMC?

Siddharth Verma

A You haven't provided any details regarding the MMC, so what we are suggesting here are mostly general solutions.



Flick the latch to remove write protection

1. If you've been using the MMC with some device like a phone or camera, then try connecting the phone/camera to the computer via USB cable. Most likely you'll be able to access the MMC in this manner.
2. You could try to access the same under Linux, it should show up.
3. Go to the manufacturer's website, you'll find tools to unlock your MMC, albeit most of them will format the card in the process.
4. If your MMC has one of those latches on the side which can be flicked to remove write protections then you could give that a go too.
5. Insert the MMC in your phone and search for a file called `mmcstore.txt`. Transfer the file to a computer and open it. Your password should be there along with a few garbage characters.

Q Offline wiki woes

I am having problem installing the offline Wikipedia. I followed the instructions which you have listed but I am having some problems. Actually installation never ends just after it is on the verge of completion and it shows around 1192 hours remaining in time left. I tried it many times but same thing happens.

Shrinil Pandya