

Camera Care

Like any other piece of electronic equipment, your digital camera is precious and should be taken care of. Leaving it out in the dust or sunlight for too long can adversely affect the performance and make-up of the camera. Here are some tips to help you take care of your camera

Keep Your Camera In A Camera Bag

An inexpensive camera bag is all you need to protect your camera from dirt, dust, and those unforeseen falls. But it would be worth the price of the camera (literally) if you invested in a quality bag that protected it from the elements. After all, you don't want to be left stranded after an arduous hike only to find that your camera isn't working...

Keep It Clean

Clean the outside of your camera by wiping it with a clean, dry cloth or soft camel's hair brush. Never use harsh or abrasive cleaners or organic



Air brush to clean your camera lens

solvents on your camera or any of its parts. These tend to react with the body and can leave permanent scars in addition to hurting the circuitry. Also, Avoid contact with oily substances such as any type of lotion. If your camera has a LCD (liquid crystal display), breath on it gently to create some moisture, then wipe it with a soft, lint-free cloth or untreated photographic lens tissue.

Keep It Dry

Most cameras are not waterproof. If your camera has been subjected to bad weather or you suspect water has gotten inside it, turn off the camera and remove the batteries and memory card. Let the camera air dry for 24 hours. If it doesn't work, contact your camera's manufacturer or an authorised service centre.