

Battery Care

General Tips

The following are a few simple rules to avoid driving your batteries beyond their normal exhaust point and worse yet, possible leakage.

- Replace all batteries at the same time.
- Do not mix new batteries with used ones.
- Do not mix rechargeable and non-rechargeable batteries.
- Do not mix alkaline, nickel-metal hydride (Ni-MH), or nickel-cadmium (Ni-Cd) types of batteries.
- Do not mix different grades or brands of batteries.
- Do not attempt to rejuvenate a battery by heating it.
- Do not recharge any battery that is not marked “rechargeable”.
- In cold weather, keep your camera warm (not hot, just warm).
- Turn off your camera when not in use.
- Limit use of your LCD, which quickly drains batteries.
- Occasionally, clean the battery compartment components with a clean pencil eraser.
- Store batteries in a cool, dry place out of the reach of children.
- If you won’t be using your camera for an extended time, remove the batteries.
- Avoid high-temperature storage.
- Batteries can be stored at low temperatures (e.g. your refrigerator) to slow the discharge rate.
- Protect batteries from condensation by storing them in a zipped plastic bag.
- Allow batteries to reach room temperature before inserting them into your camera (cold temperatures impair their performance).



A Li-Ion battery pack

Battery Choices

Not all batteries are created equal. Battery life depends significantly on age, usage conditions, type, brand, and camera. Digital cameras are very demanding—not all batteries perform well in digital cameras. In some lab tests, nickel-metal hydride