

the camera icon in My Computer, and choose Properties. Go to the Events tab, click 'Save all pictures to this folder' and specify the folder. Now, whenever you connect your camera, the pictures will be automatically downloaded to that folder.

Care And Maintenance

Carry your camera and other accessories such as memory cards, batteries, cleaning kit and tripod in a separate bag. Keep your camera covered with a plastic bag to protect it from moisture. Also, place some silica gel bags along with it to absorb moisture.

Never use paper tissue or napkins to clean lenses. They contain scratchy wood products and may damage the coating on the lense. Use a camera-cleaning kit that includes special brushes and a lens-cleaning solution. Keep the bristles of the lens-cleaning brush from coming in contact with your hands as body oil gets transferred onto them. After cleaning with a brush, put a drop of lens-cleaning solution on a lens-cleaning tissue, and clean the lens in circular motions.

Avoid high temperatures as these affect the camera. When in bright sunny light, keep the camera covered in a white towel when not in use. Keep the camera away from strong magnetic fields, as it may damage its memory card. Finally, remove the batteries and store them in a dry cool place if you do not plan to use the camera for a few weeks.

Develop Your Style

Pictures don't always have to be sharp to be good, perfect exposures don't always give the best results, camera angles don't always have to be the same. Digital photography is so inexpensive, you shouldn't feel the need to get every shot perfect. It's likely that your photographs won't be interesting if you don't take chances and explore new approaches. When you find a situation that catches your eye, shoot it from a variety of positions. If you have a zoom lens, use it. Try using exposure compensation. Keep experimenting and trying new techniques;