

7. If the ping commands works successfully, launch your browser and type in “http://<IP address of Access Point>”, for example, http://192.168.1.1, in your browser address bar, and press [Enter].

8. This will let you access the Web server of the Access Point, which has an inbuilt utility that will let you configure the Access Point according to your need. From here, you can change the SSID, IP/Subnet mask and enable or disable wireless security.

9. Do the necessary changes, and that's it. The Access Point is configured.

Now, go to the other system, which has a PCI Wi-Fi card plugged in to it, and make the following changes.

1. Switch off the system and plug in the PCI wireless card. Now turn on the system and let the card get detected by the system. Install the necessary device drivers and the configuration utility provided with the card. Restart the system to complete the installation process.

2. Now launch Control Panel and go to 'Network connections'. The window that opens will display 'Wireless Network Connections'. Right-click it, and click properties.

3. Now scroll down to the TCP/IP connection, and click once on it to highlight it, and then click properties. This will open the TCP/IP dialog box. Here, you need to assign an IP to the wireless card with the first three metrics, which in our case is 192.168.1. This should remain the same, and the last one can be any number between 0 and 254—but not the same as the one already assigned to the Access Point and the first system's LAN card.

4. Click OK to close the dialog box, which will bring you back to the Wireless Network connection properties. Again, here, click OK, and that's it.