

6. This will launch the configuration utility of the router. But to enter this utility you will have to provide a username and password, which again, is provided in the manual.

7. The first thing you should do now is change the login and password to something really difficult, which no-one can guess. Also change the security setting to at least 128-bit if you are going to access your bank account and other sensitive information.

8. You can and must change the IP address to something else, as the default IP is easily traceable, and known to most Wi-Fi users. If possible, restrict DHCP (Dynamic Host Control Protocol) to very few numbers. For example, if you are going to connect just one more system wirelessly, than restrict the start and end IP to accommodate just one machine. Change this later if you have to add one more system.

3.2: Setting Up Wireless Networking

(Windows + Mac)

Configuring the Client

The adapter card will have to be installed on the client PC, since we're going to connect the client machine to the Access Point configured on the LAN.

Here are the steps to follow in order to configure the client PC and the laptop.

1. Power down the system and remove the side cover. Locate a free PCI slot if you are going to use a PCI Wi-fi card. Secure it tightly, screw it in, and attach the detachable antenna to the card.

2. Power up the system. The PC will detect the card and ask for the drivers. Install the drivers as mentioned in the manual and restart the system if need be.