

6. The BIOS update is available in the form of a WinZip or WinRAR archive, and contains two files that are essential to the flashing of the BIOS. These are the data file and a DOS executable file that writes the BIOS information onto the BIOS chip. The filenames will be different depending on the motherboard manufacturer. Sometimes you will only see one file, which is the data file. In that case, you will need to check the support section of the motherboard manufacturer's Web site and locate the BIOS flashing tool, which will vary depending on the BIOS manufacturer. Examples are 'flash879', 'awdflash', and 'aflash'.
7. In addition to the two abovementioned files in the archive, you may also have a .bat file (a batch file) that makes the task easier for you, since all you need to do is double-click it, and the BIOS flashing process starts. There will be another file—a Readme.txt file—explaining the steps you will need to take to flash the BIOS. You may want to read that before you start flashing the BIOS.

Before starting on the flashing process, ensure that the boot order in the BIOS is set such that the computer boots from the floppy. Then follow these steps:

1. Start the computer and boot using the Windows 98 bootable floppy disk. You will reach the A: prompt.

A typical BIOS screen seen on pressing the Del key.



Go to the Advanced BIOS features to access the boot sequence setting.

