



memory in the reverse manner - it can only go into the slot in one way.

2. There are two notches on either side of the RAM module. The locks on either side of the RAM slots on the motherboard fit into these notches, securing the module in place.
3. When inserting the module in the RAM slot, check for the notch on the bottom and install the RAM module accordingly.
4. Once you have inserted the RAM modules properly, the locks on the motherboard automatically click into place.
5. Start the computer and check for the display. Once the display comes on, you will see a RAM count indicating the amount of memory installed on the computer.
6. If you haven't installed the RAM properly, you will hear constant beeps when you start the computer. Shut down the computer and re-seat the RAM properly in its slots, and restart the computer.