

outs—the layout offers you a number of different arrangements:

- m Full Page Print (single image spread on full page)
- m Contact Sheet Print (35 images on a single sheet)
- m 8 x 10 inches (one image per sheet)
- m 5 x 7 inches (one image per sheet)
- m 4 x 6 inches (three images per sheet)
- m 3.5 x 5 inches (four images per sheet)
- m Wallet Prints (nine images on a single sheet)

A preview of each of the above options is displayed alongside to give you an idea of what will be printed.

## 4.5 Using Optical Media

---

Optical Device Drives (ODD), commonly called CD/DVD drives, are well backed by Windows XP's driver database. You shouldn't find any difficulty in installing a drive. If you do encounter some sort of problem, you've either done something wrong or the device is faulty.

Hard disks and ODDs both have jumper settings for "Master," "Slave," and "Cable Select." If you have your hard disk and CD/DVD drive on the same IDE cable and if both are set to Master, then you may have only one of the device functioning at a time—in most cases, the hard disk will function and the CD/DVD will go undetected. It is good practice to maintain ODD devices on the secondary cable (there are two IDE ports, Primary and Secondary). If you have a CD/DVD-Writer, it is advisable to set it as the Secondary Master.

Windows XP comes with a CD-Writing Wizard. Although unimpressive, it can be useful to write data to CD when you do not have software to perform the task. Follow these steps to use the CD-Writing Wizard:

- m Insert a blank CD into the drive. In the window that appears, select 'Open writeable CD folder' and click 'OK'. Alternatively, just double-click the CD/DVD icon in My Computer.