

use only half the installed memory. Older machines have a limitation on the amount of system memory. If the limit is crossed, the additional megabytes go unrecognised.

**Solution:** Find out (from the BIOS setup under Advanced Chipset Features) how much MB of the system RAM is allotted to on-board graphics. Now compare the remaining amount with the amount displayed by Windows. If the count does not match, then restart the system and check with the BIOS/CMOS setup for the memory count. Failure of the BIOS to detect the entire capacity indicates incorrect choice of hardware. Refer the motherboard manual or site or dealer for suitable specifications.

► **Problem:** Address (Hexadecimal) Error Messages

Such error messages indicate a problem with the memory. They specify a hexadecimal address. For example:

**Memory failure at 0x44AE44683C**

**Memory verification error at: 0x00FC3588AE**

*(Note: The addresses specified above are not real—they're just for the sake of explanation.)*

**Cause:** The computer constantly performs read-write processes on the memory, and also verifies the authenticity of the data being processed. Errors mentioned above come up on the screen when the computer does not receive the expected data/value from the RAM. This error can be caused by a defective module or a mismatch between old and new modules.

**Solution:** Use only one RAM module at a time (remove the new module, if any) and work on your PC the way you would normally do. If you still face the problem, remove the old module and check again with only the new module inserted.

► **Problem:** Himem.sys Error

This is a common error with Windows 9x systems. The most common error messages related to this are:

**"Himem.sys missing or corrupt"**

**"ERROR: HIMEM.SYS has detected unreliable memory at address 001003A4h"**

**Cause:** Himem.sys file is a program that controls system access to