

► **Problem:** You're facing intermittent keyboard failures.

Cause: The keyboard cable or keyboard jack might be defective.

Solution: Test the cable and jack with a digital multimeter.

If there's no signal someplace, you'll need to replace the jack or the cable.

► **Problem:** Your regular keys work but not the multimedia keys.

Cause: You don't have the correct software.

Solution: Download the latest software from the manufacturer's Web site. The software is also probably present on the CD that came with the keyboard (if one did), but checking for the latest version is always recommended.



► **Problem:** Your USB keyboard doesn't work in the BIOS.

Cause: The USB legacy mode in the BIOS hasn't been enabled.

Solution: Connect a non-USB keyboard, and enable USB legacy mode in the BIOS.

► **Problem:** Your mouse doesn't work with a different port type: for example, when you're trying to connect a PS2 mouse to a USB port using an adapter.

Cause: The mouse needs to be a hybrid mouse.

Solution: Check whether the mouse is indeed of the hybrid type (designed for various ports). Use only the adapter that came with the mouse packaging.

► **Problem:** The mouse pointer jerks onscreen.

Cause: The mouse ball and/or rollers are dirty, or there's something stuck on the ball, such as a hair.

Solution: Turn the mouse upside down and unscrew the plastic cover that reveals the mouse ball. Clean it. Also clean the three rollers using your nails or a liquid such as distilled alcohol or acetone.