



tion of the Control Panel for a setting to control the typematic delay, which is the amount of time a key must be held down before it starts repeating, and increase it if you are finding the key repeating too quickly.

Solution #2: Clean the keyboard. If you are only having a problem with one key, you may want to try first just cleaning around that key cap. Of course once you open up the keyboard (if you do) you might as well clean the entire inside of the keyboard. Be careful about what you open; some keyboards cannot be reassembled once opened!

► **Problem:** There is a loud ringing or repeated beeping sound from the PC speaker when the keyboard is connected to the system.

Cause: This is usually caused by the PC getting confused when the keyboard is attached to it. Systems don't usually react well to having a keyboard attached to them when they are already on.

Solution: Turn the PC off, wait for 15 seconds, and then turn it back on.

► **Problem:** You get a "Keyboard error or no keyboard present" error during startup.

Cause: This can happen if keys have been pressed during the POST (Power On Self Test).

Solution: Make sure the keyboard is attached correctly and that no keys are pressed during POST.