



Properties in the Control Panel, and on the Cordless tab, click Connect. One of these three should solve the problem, and your mouse should get connected.

► **Problem:** Batteries in your optical mouse drain out too quickly.

Cause: You're using a bad mouse pad or no mouse pad at all.

Solution: LED-based optical mice work better with a light background (ideally, white) under them. Use a white mousepad (or any other white background) for your mouse. The batteries will last longer.

► **Problem:** On your multi-button mouse, you can't seem to assign a non-standard button to a function.

Cause: You don't have the latest drivers installed.

Solution: Download the latest drivers from the manufacturer's Web site.

► **Problem:** You have a problem defining keys in games—all of them appear as "mouse wheel up".

Cause: The cause for this could be the device drivers themselves!

Solution: Use Windows' generic drivers instead.

► **Problem:** Your computer hangs when you try to bring it out of Standby or out of Hibernation using a USB device.

Solution: To resolve this problem, obtain the latest service pack (SP2) for Microsoft Windows XP.