

the USB port. It is very important that when you reconnect the joystick, it remains centred. If that doesn't work, try the manufacturer's clear calibration utility. Most manufacturers offer this tiny utility for download on their sites, and running it will clear all registry values that relate to device calibration. Note that all calibration information might be removed for *all* game controllers from *all* manufacturers.

► **Problem:** Your joystick is jumpy or erratic in a game.

Cause: Various things can cause a gaming device to act erratically. These include problems with DirectX, calibration entries in the Windows Registry, and game issues.

Solution: Make sure you are running the latest version of DirectX. If you are unsure about what version of DirectX you are using, at a command prompt, type in "dxdiag" and press [Enter]. The box that comes up will tell you about what version of DirectX you have installed on your system. Check the Microsoft Web site (www.microsoft.com/directx) for the latest version.

You may also want to uninstall and reinstall the joystick software. In some cases, if the calibration issue is within a game, you could try uninstalling and reinstalling the game.

► **Problem:** Your game says it supports force feedback, but you don't feel any forces on your force feedback device.

Solution: In order to feel forces, the game must support the IFORCE-2 instruction set. In addition to using the IFORCE-2 instruction set, the option to feel forces must be turned on in the game. For information on enabling forces within the game or finding out if the game uses the IFORCE-2 instruction set, consult the game's documentation.