

► **Problem:** Your laser printer prints heavy on one line about two inches from the bottom.

Cause: The toner cartridge may be damaged, or the lower fuser roller may be bad.

Solution: Some printers sometimes don't pinch the paper tightly enough during fusing, causing smears. The fuser has a Teflon-coated hollow metal roller with a heat lamp inside, and another roller that pinches the paper against the hot roller during fusing. The lower roller is made of high-temperature silicone rubber. Those sometimes go bad as described above, but if you have replaced the fuser assembly recently, that isn't the problem.

Look for any rollers between the pickup roller and the fuser, and clean them with naphtha or mineral spirits. If there is a black roller with a foam-like surface, it is electrically conductive, and is part of the mechanism that places electrical charge on the paper. Clean it with alcohol, taking care not to get fingerprints on it.

Clean everything in the paper path: if there is a corona wire (instead of the conductive roller), clean it with a Q-tip dipped in alcohol. If this does not help, the toner cartridge might need to be replaced.

► **Problem:** A shared printer prints documents fired from the host computer, but not from other computers on the network.

Cause: The printer drivers have not been installed properly.

Solution: Uninstall the drivers and install them afresh. A printer connected to either a USB port or an LPT port should not in any way cause a problem while printing on a LAN.

10.1.1 How to get the best out of your inkjet printer

- Use original ink cartridges to prevent clogging, leaks and bleeding.
- Set the printer driver settings correctly.
- The best results will be achieved by matching the printer, printer settings, ink and paper.
- Handle inkjet papers like photographic papers, by the edges to avoid oil deposits and fingerprints.
- Set your printer for the proper paper type and weight. Fine art