

10.3 Other Peripheral Devices

► **Problem:** When your PC attempts to detect your Webcam, it hangs and then restarts. After restarting, the following error shows up: “[filename] is missing...”

Cause: The Web cam’s drivers are corrupt.

Solution: Download the latest drivers from the manufacturer’s Web site.

► **Problem:** When you connect your Webcam to a USB port, Windows does not detect it. (You installed it on another computer and it worked just fine.)

Cause: The onboard USB is not enabled in your motherboard.

Solution: To enable onboard USB, you need to access the BIOS setup and select the ‘Integrated Peripherals’ option. Here, you will find the options to enable/disable onboard USB. Enable it and restart your machine with the device plugged in.

► **Problem:** You are unable to use the USB ports on your PC.

Cause: The USB ports might be disabled, or there’s a problem with Windows.

Solution: Enable the USB ports in BIOS. This is usually under the Integrated Peripherals option. If you have an older version of Windows such as 95 or 98, you will need to install the USB drivers for your version of Windows either from the motherboard driver CD or from the motherboard manufacturer’s Web site.

► **Problem:** USB ports are available in the BIOS but are not visible under System in the Control Panel.

Cause: The USB header cables are not connected to the motherboard.

Solution: Some motherboards have

