

- and configure the system with or without user prompts
2. Windows will prompt the user for the OS installation CDs to retrieve the required drivers
 3. Windows will prompt the user to provide the location for the required drivers supplied by the device manufacturer.

This would be your cue to insert the manufacturer's CD that came with the device and point Windows to the correct driver installation file for the OS. Alternately, the manufacturer's installation guide may provide a different method for installation. Example: most USB devices require that you install the software first before connecting the device.

If Windows recognizes the device but you don't have the manufacturer's CD, there is a good chance that you can enable basic functionality by using the default Windows drivers. See the section *Installation of non-Plug and Play Devices* on how to tell Windows to use the default Windows drivers.

1.5.5 Installation of non-Plug and Play devices

If the device is not getting detected by Plug and Play during system startup, this usually means that you have a non-Plug and Play device. If you have the manufacturer's CD and/or manual, look for installation instructions. Non-Plug and Play devices are usually older, and require manual allocation of resources, usually through setting jumpers or switchers on the device itself. Once you have ensured that the device has been configured as per the manufacturer's guidelines, boot up and install any software provided by the manufacturer as per the installation guidelines.

If there are no installation guidelines or the device is a second hand component with no documentation or you don't have the required software drivers, then you can try to force Windows to recognise the device. First try to verify if the physical installation and the jumper/switch settings on the device are correct. Search the Internet for information on how to do this. If you are able to do this, good; if not, don't worry