

Get an updated driver for the device from the manufacturer and update the device software by clicking Update Driver on the Driver tab.

AND/OR

Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

Code 3

Code Meaning: The driver is corrupt or your system is running low on memory and other resources.

Recommended Resolution: Run the Update Driver Wizard and reinstall the driver or get an updated driver from the manufacturer.

AND/OR

Close any applications using memory.

AND/OR

Add more RAM. See the chapter on Memory on how to do that.

AND/OR

Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

Code 4

Code Meaning: (Not applicable to Windows XP) One of the drivers for the device may have been corrupted, or its Windows Registry entry may be damaged.

Recommended Resolution: Check the registry by running scanregw.exe. Click **Start > Run**. Type **scanregw.exe** and hit [Enter]. This program will check the Registry for corruption and prompt you to restore a previous good version of the Registry if it encounters any damaged entries.

AND

Remove the device from Device Manager and reinstall it using Add Hardware Wizard.

Code 5

Code Meaning: (Not applicable to Windows XP) The device has requested a resource that Windows doesn't know how to handle.

Recommended Resolution: Run the Update Driver Wizard and rein-