

Code 37

Code Meaning: The driver software failed to load.

Recommended Resolution: Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

Code 38

Code Meaning: The driver software is already loaded into RAM and cannot be loaded again.

Recommended Resolution: Restart the computer.

Code 39

Code Meaning: Some or all the drivers could not be loaded as they may be corrupted or missing.

Recommended Resolution: Remove the device from Device Manager and reinstall it using the Add Hardware Wizard. Update the driver if possible.

Code 40

Code Meaning: The driver's Registry entry is either corrupted or missing.

Recommended Resolution: Remove the device from Device Manager and reinstall it using the Add Hardware Wizard. Update the driver if possible.

Code 41

Code Meaning: This usually happens when Windows cannot detect non-Plug and Play devices.

Recommended Resolution: Obtain an updated driver for the device from the manufacturer. Remove the device from Device Manager and reinstall it using the Add Hardware Wizard. Update the driver if possible.

Code 42

Code Meaning: A (system bus) driver has created duplicate entries, or a serial number is discovered in a new location before it is removed from the old location.

Recommended Resolution: Restart the computer.