

Code 43

Code Meaning: One of the drivers controlling the device notified Windows that the hardware has failed in some manner, and Windows stopped the device.

Recommended Resolution: Refer to the hardware documentation or the manufacturer's Web site to resolve this error.

Code 44

Code Meaning: A software program or system service has shut down the hardware.

Recommended Resolution: Restart the computer.

Code 45

Code Meaning: The hardware is not connected to the computer. This error is reported when the computer is set to show all devices previously connected to the computer.

Recommended Resolution: Reconnect the hardware or ignore the error. No resolution is necessary.

Code 46

Code Meaning: Windows is not able to access the device as the system is shutting down.

Recommended Resolution: The device should work correctly when the computer restarts.

Code 47

Code Meaning: The device has been prepared for safe removal either by unplugging or pressing an eject button.

Recommended Resolution: Unplug or eject the device and then plug it or insert it back in to bring the device back online. *Note:* Restarting the computer also brings the device back online.

Code 48

Code Meaning: The driver for the device is known to have problems with Windows.

Recommended Resolution: Obtain an updated driver from the device manufacturer and update the driver.