

3.2.7 The screen twists with wavy lines and the picture bends

Cause: This is caused by electromagnetic interference (EMI) from some other appliance such as a fan, motor, or even other monitors, either very close to the monitor or on the same power circuit.

Solution: Move the other appliance out of range of the monitor or off the same power circuit. If the symptom continues, there could be an EMI problem with the monitor itself. Have it checked at the repair shop.

3.2.8 Images are blurred

Cause: This may be a problem with the display settings of the monitor, or with the signal cable

Solution: Adjust the display. There might be an option called 'Focus' or 'Sharpness'. Adjust that setting. If that doesn't work, check the cable and its connection to the PC.

3.2.9 There is some irregular discoloration along the edges of the screen

Cause: This is caused by the magnetisation of the metallic elements on the surface of the CRT. The magnetisation happens because of EMI or due to sudden knocks to the body.

Solution: Cycle through the display controls and select the Degauss option. Degaussing is the process of demagnetising the CRT.



A monitor being degaussed