

the General Tab, select “Obtain an IP address automatically” and click OK twice.

8. To enable automatic wireless network configuration. To do that, right-click on the wireless connection and select Properties, select the Wireless Networks tab, ensure that the box that says “Use Windows to configure my wireless network settings” is checked.

Installation

If possible, start the Wireless Network Setup Wizard on a computer that is connected to a printer, so you can use the configuration information printout to manually configure wireless devices that do not support Windows Connect Now technology.



Use the Wireless Setup Wizard