



Transfer Wireless Setting to the Pen Drive

6. Take the USB drive and plug it into your Windows Connect Now enabled Wireless Access Point. If your AP does not support Windows Connect Now, skip this step. If there is a read-out display, select the options to complete the configuration. If there is a no read-out display, the indicator panel should have a green LED that flashes three times when configuration is complete. Some AP vendors use the LED indicators for other purposes, so be sure to refer to the documentation. In any case, leave the USB drive in for at least 30 to 60 seconds to ensure that the network configuration is updated to the AP.
7. Follow the above procedure if you have any other wireless devices (such as printers) that are Windows Connect Now capable.