

order automatically get subtracted from the inventory. In case of indefinite work orders, the inventory items are subtracted when the technician working on the order closes them.

5.2.4 The Web interface

A unique feature of Maintenance Assistance is its Web interface. During installation, the software automatically create a server that will then enable access via the intranet or via the Internet. You can have your employees access the inventory and their work orders from anywhere in the world. The only requirements is that



An employee's view of the Web interface

the computer must have a copy of Maintenance Assistance running on the computer. To ensure that the employee can access the work order records, the Maintenance Assistant software has to be running on the server as well.

Employees log into the software using their login IDs. Once logged in, clicking on the Web Interface tab takes them to the work order page, which opens in the Web browser. From there on, they can check various settings.

Any work orders assigned to the employee will show up first based on their priority and then based on the time allotted to the task. Once a task is completed, the employee can close the work order. Doing that will subtract the inventory items used from the available stock.

While connecting to the software from outside the intranet, you need to first make sure your server's network is set up for