

that ISO 200 needs a lower exposure time or smaller aperture setting than ISO 100. Higher ISO settings are suitable for situations where the ambient light is low.

5.4.11 Lens

The lens is one of the most important and expensive parts of a camera, and often makes the difference between a great photograph and a photograph. A camera may use a single lens, or a combination of lenses, which might be attached to the camera body, or detachable. Lenses are of many types, depending on what is being shot. Macro lenses are used to shoot at very small distances; telephoto lenses are suitable for objects at large distances. Wide-angle lenses (like the fisheye lens) are used for situations that need a wider angle of vision. Another category is the zoom lens, whose focal length can be varied, and is most commonly seen in point-and-shoot digital cameras.

5.4.12 Macro

A mode of photography where the subject is very close to the lens. Modern digital cameras have a setting for macro photography.

5.4.13 Noise

Imperfection caused in the output from digital photos when the pixels are not sufficiently exposed to light. Too much noise makes the finished photograph look grainy. Noise can be reduced by the camera's sensors, and also with the appropriate light settings.

5.4.14 Shooting modes

A camera needs different settings for shooting photographs in different scenarios. For example, shooting subjects at night needs a different aperture, ISO, flash settings, etc. than when shooting subjects at the beach in daylight. Typical preset shooting modes that modern digital cameras come with include Auto, Portrait, Night, Landscape, and Macro.

5.4.15 White balance

This is a setting that makes it possible for objects that appear white to the eye appear the same in photos, irrespective of the