

Autumn:

The autumn mode sets a warm tone for the image, increasing the saturation of the reds and yellows, and as a result, related colours like brown and orange. You can automatically set all other settings such as the aperture, exposure and shutter speed.

Baby:

A small aperture and high shutter speed is used for this setting to capture kids in action. White balance is set to capture softer hues.

Beach:

The beach mode is used differently in different cameras. Some cameras increase the saturation of warm colours to bring out the sand and the sun better. Some cameras increase the saturation of blue to highlight the sea.

In sunny conditions, the face is often in shadow because of a cap or because the sun is so bright in the background. Some cameras use a flash or artificial brightening algorithms to make sure that people in the photograph are not silhouetted by the sunlight.

Colour Accent:

This feature lets you pick a particular colour, and then retains only that colour in any image you click, by converting all other colours to a monochrome black-and-white photograph. This means that against a greyscale image, an object of a single colour will stand out.

Colour Swap:

This feature lets you select a particular colour, and then change it to another colour that you select, while not shifting the hue of any other colour in the photograph.

Easy:

The easy mode lets the camera do all the work — all you need to do is click in peace. This mode is to allow kids use the camera. Some cameras increase the size of the menu in this mode for easier navigation.