

Fireworks:

This mode uses the slowest shutter speed possible, so that the entire explosion of a firecracker is captured on the image. This also means that the aperture will be very small, with consequently a smaller depth of field. Images taken in this mode are bound to be a little blurred, but that is the idea when photographing firecrackers.

Flower:

The flower mode increases the depth of field by using a small aperture to bring to focus subjects close to the lens. This mode also increases the saturation of the colours in the photo, to produce a bright and vivid image of flowers.

Foliage:

Not to be confused with the macro mode, the foliage mode increases the saturation of green or naturally occurring bright colours to provide clear and vivid images of flowers or leaves.

Indoor:

This mode is for low-light conditions indoors, with changes made to the white balance to optimise indoor conditions, and capture the natural ambience of soft lighting conditions. A high ISO is typically used in this mode.

Kids and Pets:

Similar to the action or sports mode, this setting uses a small aperture and a fast shutter speed. This allows for clear images of small kids and pets in action. Do not use this mode to capture stationary kids and pets.

Landscape:

The landscape mode narrows the aperture (a large f-stop value) to increase the depth of field as far as possible. This allows objects in the distance to be in sharp focus, as well as anything close to the camera. A fast shutter speed and a high ISO are used in this setting, and should be used to capture anything from cityscapes to photos from a height.