

Portrait:

A standard feature in most digital cameras, the portrait mode uses a larger aperture size than the macro mode, but smaller than the landscape mode. This means that when you focus on subjects in the foreground, but not too close to the camera, the background will be out of focus. This draws the eye to the subject in the foreground of the final photo as the background is out of focus. A small aperture and a small depth of field are used.

Program AE:

The program AE or program mode automatically sets the shutter speed and the aperture in the camera, letting the user play around with other features such as the white balance and whether or not to use the flash.

Red-eye reduction:

This mode uses an algorithm that reduces the red eyes in photos. The camera settings are similar to the settings used in portrait mode.

Shutter priority/preferred (Tv):

The shutter priority mode allows a user to set the shutter speed of the camera, and the camera sets the other settings automatically. The shutter speed lets the user decide how sharp or blurred the image should be.

Snow:

The snow mode is used to set the white balance in such a way that a white background does not make people or objects in the foreground appear dark. Also the overwhelming white background is toned down, to capture subtler hues of blue or green. This is similar to the beach mode in terms of not letting a subject appear dark.

Stitch/Panorama:

The stitch or panorama mode in cameras typically allows three photos to provide a wide angle image. A section of the image appears to one side of the screen to allow users to overlay the next shot.