

Sunset:

The sunset mode changes the white balance to capture the deeper and subtler hues that appear during a sunset. This mode also reduces the glare of shooting the sun directly in some cameras. A warm tone is applied to the image.

Text/Document:

The text or document mode in cameras optimises the white balance by whitening the white areas, while darkening the black areas. The image is also made crisper and sharper, which makes this mode ideal for shooting all forms of written text, like a ticker, a road sign, graffiti or documents.

Theatre:

The theatre mode suppresses the flash, uses a large aperture and a slow shutter speed to capture images inside an auditorium where flash is not allowed. Some cameras also increase the vividity, and the brightness or ISO settings artificially.

Underwater:

The underwater mode, where available, suppresses flash, uses high ISO speeds and desaturates the blue coloration to give a natural photo underwater.

Video:

The video mode allows capture of motion on camera. The duration of the video may vary from 5 seconds to 10 minutes and larger depending on the memory and the camera. There are also a few image size settings available in most cameras. The camera settings for the video are handled automatically with little or no control available to the users.

1.4 White Balance

Whether it is fluorescent lighting, or low-light conditions during sunset, humans can differentiate between colours without any effort. This, however, is not the case with a camera. The sensor in the camera just records the image with respect to the amount of light falling on it. The reflected light from an object is affected by the colour temperature of the light source.