

Shooting Modes

Cameras typically employ two main shooting modes — single and burst. Both of them are meant for different situations.



Shooting modes are usually available in the user interface

6.1 Single shoot

The single shooting mode is most commonly used by photographers. This mode is selected by default when you turn the camera on. As the name suggests, it sets the camera to capture a single image on each click. This works great in stable environments without sudden movements where there's a chance of a photo going bad.