

If you see any fingerprints or dirt on the lens, then use an air blower to gently blow the dirt away. For more stubborn dirt marks, use a fibre cloth or lens cleaning solutions. Never pour any solution directly onto the lens, but use a soft cloth dipped in the solution.

Even more care is to be taken when the sensor itself has some kind of dirt on it. Stains and dirt on the sensor



Lens cleaning kits for cameras are available



Sensor cleaning is necessary at times with a soft cotton bud

are comparatively rare, but if indeed you get any, it should be cleaned in a similar manner. You can wipe the rest the camera using a cloth. If there are any creases or gaps that can't be reached with a cloth, a soft brush or an air blower can be used.

Avoid carrying the camera to sandy places and especially keep the camera out for long in extreme temperatures. Also check the memory and battery slots for any dirt or sand. Use a blower to clean them. Avoid keeping batteries inside the camera for as long as months. Humidity and fungus are always a problem as far as storing cameras is concerned. Keep some silica gel along with the camera if possible.



It's also advisable to get the camera checked and

Silica gel helps reduce moisture and growth of any kind of fungus