

cleaned at an authorised service centre every once in a while. Some manufacturers even sell specialised kits with everything needed to clean your camera.

11.2 Carry bag

The camera should be carried around in a bag as much as possible. Point-and-shoot cameras should be kept in a pouch, while DSLRs should preferably be stored in a carry bag. While purchasing a carry bag, you should look for one with compartments to keep the other accessories such as the flash, the lens and so on. If you are looking forward to purchasing even more lenses, then there should be provision for those. Some even have a small external strap made to hold a folded tripod.

A DSLR isn't something you put into a small pocket and carry along. A good photographer always carries the entire kit along. The carry bag should be sturdy and well padded from within, so different components of the camera don't brush against each other damaging themselves.

11.3 Microfiber cloth

Standard cloth isn't very fine and has a tendency to grab and hold on to sharp particles. When such a cloth is used, there is a good chance that you will scratch your lens or sensor. We recommend that you use a good quality microfiber cloth to clean your lenses and cameras. While cleaning the lens with a microfiber cloth,



Using a microfiber cloth is a safe way to clean the lens and screen

make a circular motion to clean the lens. Microfiber cloth is also used to clean LCD screens and other delicate items. Use a microfiber cloth to clean the screen on your camera every now and then. If you own a DSLR, it's also a good idea to purchase a screen-guard for your camera. Some cameras even come with a hard foldable plastic cover that covers the screen.