

Syntax:	#fuse options
Elements:	options vary depending on the device. A list of all valid options is always present at the top of each devices .h file in a comment for reference. The CCS PCW device edit utility can modify a particular devices fuses. The PCW pull down menu VIEW Valid fuses will show all fuses with their descriptions. Some common options are: LP, XT, HS, RC WDT, NOWDT PROTECT, NOPROTECT PUT, NOPUT (Power Up Timer) BROWNOUT, NOBROWNOUT
Purpose:	This directive defines what fuses should be set in the part when it is programmed. This directive does not affect the compilation; however, the information is put in the output files. If the fuses need to be in Parallax format, add a PAR option. SWAP has the special function of swapping (from the Microchip standard) the high and low BYTES of non-program data in the Hex file. This is required for some device programmers. Some processors allow different levels for certain fuses. To access these levels, assign a value to the fuse. For example, on the 18F452, the fuse PROTECT=6 would place the value 6 into CONFIG5L, protecting code blocks 0 and 3. When linking multiple compilation units be aware this directive applies to the final object file. Later files in the import list may reverse settings in previous files.
Examples:	#fuses HS,NOWDT

#DEFINE

Syntax:

```
#define id text
      or
#define id(x,y...)  text
```

Elements:

id is a preprocessor identifier, text is any text, x,y and so on are local preprocessor identifiers, and in this form there may be one or more identifiers separated by commas.