

RS232 I/O	ASSERT()	GETCH()	PUTC()	
	FGETC()	GETCHAR()	PUTCHAR()	
	FGETS()	GETS()	PUTS()	
	FPRINTF()	KBHIT()	SET_UART_SPEED()	
	FPUTC()	PERROR()	SETUP_UART()	
	FPUTS()	PRINTF()		
SPI TWO WIRE I/O	SETUP_SPI()	SPI_DATA_IS_IN()	SPI_READ()	SPI_WRITE()
	SPI_XFER()			
DISCRETE I/O	GET_TRISx()	INPUT_K()	OUTPUT_FLOAT()	SET_TRIS_B()
	INPUT()	INPUT_STATE()	OUTPUT_G()	SET_TRIS_C()
	INPUT_A()	INPUT_x()	OUTPUT_H()	SET_TRIS_D()
	INPUT_B()	OUTPUT_A()	OUTPUT_HIGH()	SET_TRIS_E()
	INPUT_C()	OUTPUT_B()	OUTPUT_J()	SET_TRIS_F()
	INPUT_D()	OUTPUT_BIT()	OUTPUT_K()	SET_TRIS_G()
	INPUT_E()	OUTPUT_C()	OUTPUT_LOW()	SET_TRIS_H()
	INPUT_F()	OUTPUT_D()	OUTPUT_TOGGLE()	SET_TRIS_J()
	INPUT_G()	OUTPUT_DRIVE()	PORT_A_PULSUS()	SET_TRIS_K()
	INPUT_H()	OUTPUT_E()	PORT_B_PULSUS()	
	INPUT_J()	OUTPUT_F()	SET_TRIS_A()	
PARALLEL SLAVE I/O	PSP_INPUT_FULL()	PSP_OVERFLOW()		
	PSP_OUTPUT_FULL()	SETUP_PSP()		