

with a sliding bar to get in closer or move out of your shot. On rotating your camera to change between landscape-style and vertical-portrait style shots your settings screen will automatically rotate and move to the bottom. On some Android



You can choose between camera or camcorder from the button on the right

phones you can even try out a half-press on the shutter to focus your lens and see what the final resulting shot will look like. This may work on some phones but a lot of manufacturers like HTC do not support such features. If your camera does have a dedicated button for the camera, you might be able to press it until you feel a tiny bit of resistance and no further, allowing you to perfectly time a shot- you have already focused and lined up your shot and all you have to do is release the button at the exact moment. Depending on your phone, there may be many more features to explore. For instance, your HTC may have the Sense interface, where the camera controls are in mostly the same places the standard Android setup but some extra unique tools are added. You can change the focus from the center and shift it elsewhere by simply tapping on a set of points in a shot on an HTC or dragging the focus brackets on a Motorola.

6.2 Videos

Similarly video isn't all that different from clicking pictures on your Android. On most phones the application will actually be the same only and just flicking the screen allows you to toggle between camera and video and the zoom control becomes a video quality setting. On some phones there may be a separate app to launch a video recording called Camcorder, which serves the same function as opening the camera and changing the mode to video. Display options will be available just like the Camera for adjusting lighting, balance and so on, and you can record or stop by pressing the same control button. Extra features are added to the platform by various manufacturers like the Motorola Scenes offering through which you can