

to the previous screen. If you keep pressing the Back button, eventually you'll get to the Start screen.

- ▶ **Start:** Pressing the Start button takes you directly to the Start screen. The icon, is a silhouette of the familiar Windows icon. The Start button comes in handy when you want to change what you're doing with the phone, such as going from browsing the Web to making a phone call.



The Windows Phone 7 start screen

- ▶ **Search:** Use the Search button to find information on your device. When you press the Search button, a Search screen pops up along with a small software keyboard so that you can enter the text to describe what you want to search for. The search is based on the application you're using at the moment. If you're in the phone application, the Search button searches your telephone book for a contact based on the text you enter. If you're on the Internet, it searches the Web. If you're on the Start screen, it searches the whole phone.
- ▶ **Side buttons:** In addition to the three buttons on the front, there are three buttons on the side of the phone: the Power button, the Camera button, and the Volume button.
- ▶ **Power:** The Power button is on top of the phone. In addition to powering up the phone, it puts the device into sleep mode if you press it for a moment while the phone is on. Sleep mode shuts off the screen, suspends any running applications, and turns off the radios in the phone. The advantage of Sleep mode (over completely turning off the phone) is that hitting any of the hardware buttons wakes up the phone, it's ready to operate in just a few seconds. If you turn off the phone, it takes longer to start back up. You can't receive any calls while your phone is in sleep