

Make phone calls

Even with a fancy smartphone like your Windows Phone 7 device, sometimes all one needs or wants from a phone is the ability to make a call. This section will show you all the different ways you can place a call from your Windows Phone 7 smartphone, including a few smart ways to get connected fast!

Dial a number

Know the number of your favorite chinese restaurant by heart? Dialing a number is a pretty simple affair.

1. Turn on your phone and unlock it. Then press the Phone live tile. It should display the current cellular network you're connected to.
2. A screen showing by default your call history, or recently called numbers shows up.
3. Tap the Keypad button at the bottom of the screen to bring up the numeric keypad.
4. Dial the number you wish to call and press call. If you wish to simply save the number to one of your contacts, you can press the save button. This will launch the contact picker, allowing you to attach it to an existing contact or create a new one.
5. While on the call, the screen shows an end call button , a keypad button that you'll use if you need to enter numbers while on the call (for example, navigating a customer service phone system) and a button with two small arrows that show more options. Tap that button to access in-call options.
6. The in-call options let you choose to activate the speaker phone, mute your side of the call so that the other party can't hear you sneeze, hold the call, and add calls to the current call or create a conference call.
7. When you're done with your call, click end call and the call will be terminated. You'll see that the number you dialed (or name of the person) now appears in the call history.



The phone interface