

Windows Live Sky-Drive, for automatic sharing. Because this can impact battery life and requires a data connection, it's disabled (Off) by default.

- ▶ **Keep location info on uploaded pictures:** If you manually or automatically share photos from Windows Phone, the GPS-based location data will be included with those photos. You may not want that, however, for privacy reasons. If so, set this option to Off. (It's On by default.)
- ▶ **Quick upload account:** You can configure either Windows Live Sky-Drive or Facebook as your Quick Upload Account, providing you with a slightly faster way to manually share photos to that account.

Zune: Music + Videos

One of the interesting design choices that Microsoft made with Windows Phone is that it doesn't really offer much in the way of PC/phone integration. In fact, if you plug a Windows Phone into a Windows-based PC using its USB charge cable, there's precious little you can do from there. Even after downloading drivers, Windows Phone won't show up as an icon in Windows Explorer, and thus it can't be used as a portable hard drive. And you can't download photos from the device using the built-in Windows photo acquisition software as you would with a traditional digital camera (or with competing smart phones).

As it turns out, there's only one thing you can do with your phone when it's attached to a Windows-based PC: You use Microsoft's Zune PC software to synchronise content—typically music, videos, and photo content—between your PC and the device. So for purposes of this discussion, I'll examine the initial PC-Windows Phone linkup via the Zune PC software,



Quick Play lets you quickly interact with your favourite songs